

THE FRUIT DOCTOR

SULFUR DIOXIDE (SO₂) FUMIGATION

USE INSTRUCTIONS

TRUCK FUMIGATION - FULL LOAD.

Trailers fumigated with SO₂ must be held for 24 hours before releasing for shipment.

1. Attach 2 ft. poly-flo plastic to right or left pallet stringer. Use only Snowden provided plastic staples or Arrow T-25M Stapler with 9/16" staples. Hose MUST BE SECURE. Additional staples may be required.
2. Insert brass receptacle on rubber hose into end of poly-flo plastic.
3. Insert knurled end of hose down floor drain. Close doors.
4. Connect knurled end of hose FINGER TIGHT to cylinder.
5. Turn cylinder upside down. Open slowly. Discharge completely (approximately 1 minute).
6. When empty, close stem. Disconnect hose. Pull hose straight down from drain hole, releasing it from poly-flo plastic for reuse.

.....

TRUCK FUMIGATION - PARTIAL LOAD.

Trailers fumigated with SO₂ must be held for 24 hours before releasing for shipment.

1. Close doors. Insert pipe UP through drain hole.
2. Connect knurled end of hose FINGER TIGHT to cylinder.
3. Turn cylinder upside down. Open slowly. Discharge completely (approximately 1 minute).
4. When empty, close stem. Remove pipe from drain hole for reuse.

.....

IMPORTANT NOTE:

- Truck must be on level surface to prevent back flow of liquid SO₂ through floor drain.
- Metal pipe for partial loads not to be used on full loads.

.....

GAS ROOM FUMIGATION.

1. Connect knurled end of hose FINGER TIGHT to cylinder.
2. Turn cylinder upside down. Open slowly. Discharge completely (approximately 1 minute).
3. When empty, close stem. Disconnect.

.....

RAIL CAR FUMIGATION.

1. Insert pipe into door opening at floor level. Close doors leaving hose outside.
2. Connect knurled end of hose FINGER TIGHT to cylinder.
3. Turn cylinder upside down. Open slowly. Discharge completely (approximately 1 minute).
4. When empty, close stem. Disconnect.
5. Remove pipe from doors.

.....

See Application Manual For Additional Information.

SNOWDEN ENTERPRISES, INC.
Fresno Modesto